



## **ASSEMBLY INSTRUCTION**

### DFG-MG-DB18——DFG-MG-DB30



### Warning: Excessive weight hazard!

Use two or more people to move, assemble, or install cabinets to avoid back injury. do not leave children unattended near cabinets. high risk of tipping if cabinets are installed incorrectly: securely attach cabinets to the wall to avoid serious injury.







### Safety and Care Advice

#### Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you heve enough space to layout the parts before starting.
- During assembly do not stand or put weight on the product. this could cause damage.
- Assemble the item as close to its final position (in lhe same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people .



 Toreouce the likelihood of damaging your product please ensure that your

power drill is set on a low torque setting.

#### Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste.
  Take to your local authority waste disposal centre,

#### Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- •Regularly check and ensure that all bolts and fittings are tightend properly,

#### **WARNING**

In order to help prevent overturning - please follow these instructions

To help prevent product toppling over please follow the below steps:

Use the anti tip strap or wall fixing method provided (if applicable)

Do not allow children to climb or hang on the furniture


Do not open more than one drawer at a time

Do not place heavy items in the top drawers

Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


Please note that only the anti tip strap is provided.

You will need to provide wall plugs and screws applicable for your wall type





## **PRODUCT PARTS**


	LEFT SIDE PANEL		RIGHT SIDE PANEL		DECK
LSP		RSP		DE	
	1PC(S)		1PC(S)		1PC(S)
	CONNECTING PANEL		DRAWER FACE		BACK PANEL
FCP		DF		ВР	
	5PC(S)		3PC(S)		1PC(S)
	LEFT DRAWER SIDE		RIGHT DRAWER SIDE		DRAWER FACE
LD		RD		(DDF)	
	4PC(S)		4PC(S)		1PC(S)
	DRAWER BACK		DRAWER BOTTOM		CONNECTING PANEL
BD		DD		DCP	
	4PC(S)		4PC(S)		2PC(S)





### **RECOMMENDED TOOLS**

















































7/18







































x 4











x 4

